


SERVICE DRAWING

MODEL NO. 9030



SPARE PARTS LIST

MODEL NO. 9030

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	924216-2	WING BOLT M5X15	1	
002	942101-7	SPRING WASHER 5	1	
003	941101-4	FLAT WASHER 5	1	
005	157858-9	GEAR HOUSING	1	
006	252605-4	WING NUT M16	1	
007	253052-2	FLAT WASHER 12	1	
008	231056-4	COMPRESSION SPRING 13	1	
010	252026-0	HEX. NUT M8-17	1	
011	253904-7	WAVE WASHER 12	2	
012	164298-4	ARM	1	
013	154231-4	ANGLE STAY	1	
014	951116-3	SPRING PIN 4-20	1	
015	261015-4	WASHER 12	1	
016	253052-2	FLAT WASHER 12	1	
017	222019-1	PULLEY 30-25	1	
018	212104-8	NEEDLE BEARING 1212	1	
019	253052-2	FLAT WASHER 12	1	
020	261015-4	WASHER 12	1	
021	325078-5	TOP PULLEY SHAFT	1	
023	251287-9	+ PAN HEAD SCREW M4X10	1	
024	942051-6	SPRING WASHER 4	1	
025	343065-2	SIDE COVER	1	
026	222018-3	PULLEY 33-64	1	
027	911116-5	PAN HEAD SCREW M4X12	4	
028	285623-7	BEARING RETAINER 48	1	
029	211303-9	BALL BEARING 6004LB	1	
030	221095-2	HELICAL GEAR 45	1	
031	254002-0	WOODRUFF KEY 3	1	
032	256009-2	PIN 4.5	1	
033	323224-4	DRIVING SHAFT	1	
034	212004-2	NEEDLE BEARING 810	1	
035	953106-2	RIVET 0-5	2	
036	811647-3	NAME PLATE 9030	1	
037	643550-8	BRUSH HOLDER CAP 5-8	2	
038	181021-2	CARBON BRUSH CB-51	1	
039	911159-7	PAN HEAD SCREW M4X30	3	
040	521105-8	FIELD ASS'Y 220V	1	220V
041	211028-5	BALL BEARING 627LB	1	
042	253058-0	FLAT WASHER 7	1	
043	511105-6	ARMATURE ASS'Y 220V	1	220V
044	241031-2	FAN 62	1	
045	210005-4	BALL BEARING 608DDW	1	
046	263002-9	RUBBER PIN 4	1	
047	911175-9	PAN HEAD SCREW M4X45	2	
049	931102-0	HEX. NUT M4	3	
050	411003-3	GRIP COVER	1	
051	911133-5	PAN HEAD SCREW M4X18	2	
052	687031-2	STRAIN RELIEF	1	
053	665516-8	POWER SUPPLY CORD 1.00-2-2.5	1	
054	682502-4	CORD GUARD 8-85	1	
055	645200-1	NOISE SUPPRESSOR	1	
056	*****	*****	***	*****
058	911148-2	PAN HEAD SCREW M4X25	3	

SPARE PARTS LIST

MODEL NO. 9030

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
059	941052-1	FLAT WASHER 4	1	
400	794013-8	ABRASIVE BELT SET 30X533	1	
