


SERVICE DRAWING

MODEL NO. 9505BH



SPARE PARTS LIST

MODEL NO. 9505BH

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	911136-9	PAN HEAD SCREW M4X20	4	
002	157393-7	GEAR HOUSING COMPLETE	1	
003	221357-8	SPIRAL BEVEL GEAR 11	1	
004	211088-7	BALL BEARING 6000DDW	1	
005	341398-9	PLATE	1	
006	241509-5	FAN 60	1	
007	511908-8	ARMATURE ASS'Y 220V	1	220V
008	911596-5	PAN HEAD SCREW M4X70	2	
009	681614-0	INSULATION WASHER	1	
010	*****	*****	***	*****
011	521503-6	FIELD ASS'Y 220V	1	
012	159175-3	MOTOR HOUSING	1	
013	263002-9	RUBBER PIN 4	1	
016	911198-7	PAN HEAD SCREW M4X70	2	
017	665516-8	POWER SUPPLY CORD 1.00-2-2.5	1	
018	410190-5	REAR COVER	1	
019	645173-8	NOISE SUPPRESSOR	1	
020	682502-4	CORD GUARD 8-85	1	
021	911111-5	PAN HEAD SCREW M4X10	2	
022	651651-8	SWITCH SS203KY-4	1	
023	911133-5	PAN HEAD SCREW M4X18	2	
024	410191-3	SWITCH HOLDER	1	
025	687001-1	STRAIN RELIEF	1	
026	911128-8	PAN HEAD SCREW M4X16	2	
027	687637-6	SET PLATE	1	
029	856797-7	NAME PLATE 9505BH	1	
030	643550-8	BRUSH HOLDER CAP 5-8	2	
031	191628-6	CARBON BRUSH CB-65	1	
032	414659-1	SWITCH LEVER	1	
033	254002-0	WOODRUFF KEY 3	1	
034	961052-5	RETAINING RING S-12	1	
035	221356-0	SPIRAL BEVEL GEAR 36	1	
036	962151-6	RETAINING RING R-32	1	
037	211106-1	BALL BEARING 6201LLB	1	
038	253055-6	FLAT WASHER 12	1	
039	321816-3	SPINDLE	1	
040	443034-4	FELT RING 18	1	
041	312998-2	BEARING BOX	1	
042	911121-2	PAN HEAD SCREW M4X14	4	
043	251259-4	+ PAN HEAD SCREW M5X16	1	
044	134440-1	WHEEL COVER 125 ASS'Y	1	
045	*****	*****	***	*****
046	*****	*****	***	*****
400	152490-4	GRIP 36 COMPLETE	1	
401	782412-6	LOCK NUT WRENCH 28	1	
404	782407-9	LOCK NUT WRENCH 35	1	