


SERVICE DRAWING

MODEL NO. 9901



SPARE PARTS LIST

MODEL NO. 9901

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	122329-5	DUST BAG ASS'Y	1	
002	410602-8	FASTENER	1	
003	665852-2	POWER SUPPLY CORD 1.0-2-2.0	1	
004	682516-3	CORD GUARD 9.3-85	1	
005	645200-1	NOISE SUPPRESSOR	1	
006	*****	*****	***	*****
007	*****	*****	***	*****
008	263002-9	RUBBER PIN 4	1	
009	211064-1	BALL BEARING 6000	1	
010	253758-2	FLAT WASHER 10	1	
011	221749-1	HELICAL GEAR 67	1	
012	256101-4	PIN 3	1	
013	253310-6	THIN WASHER 10	5	
014	961006-2	RETAINING RING S-10	1	
015	263002-9	RUBBER PIN 4	1	
016	152384-3	BRACKET	1	
017	241856-4	FAN 72	1	
018	343356-1	DUST COVER	1	
019	222122-8	PULLEY 10-38.3	1	
020	911143-2	PAN HEAD SCREW M4X22	4	
021	253139-0	FLAT WASHER 8	1	
022	210002-0	BALL BEARING 608LH	1	
023	221786-5	HELICAL GEAR 11	1	
024	211019-6	BALL BEARING 626	1	
025	286026-8	CAP 18	1	
026	222121-0	PULLEY 10-22.1 (L)	1	
027	855842-5	NAME PLATE 9901	1	
028	911209-8	PAN HEAD SCREW M5X10	1	
029	181030-1	CARBON BRUSH CB-100	1	
030	643600-9	BRUSH HOLDER CAP 6-10	2	
031	253707-9	FLAT WASHER 16	1	
032	231225-7	COMPRESSION SPRING 16	1	
033	253707-9	FLAT WASHER 16	1	
034	251815-0	SCREW M6X25	1	
035	225064-5	BELT 8-269	1	
036	410787-0	BELT COVER	1	
037	911243-8	PAN HEAD SCREW M5X25	1	
038	522643-3	FIELD ASS'Y 220V	1	
039	210005-4	BALL BEARING 608DDW	1	
040	253778-6	FLAT WASHER 8	1	
041	518618-8	ARMATURE ASS'Y 220V	1	
042	241833-6	FAN 70	1	
043	211033-2	BALL BEARING 608LB	1	
044	263002-9	RUBBER PIN 4	1	
045	263002-9	RUBBER PIN 4	1	
046	911243-8	PAN HEAD SCREW M5X25	4	
047	232092-3	LEAF SPRING	1	
048	911263-2	PAN HEAD SCREW M5X40	5	
049	961006-2	RETAINING RING S-10	1	
050	253981-9	CUP WASHER 10	1	
051	152319-4	TENSION ROLLER COMPLETE	1	
052	253981-9	CUP WASHER 10	1	
053	163257-5	TENSION ROLLER ARM	1	

SPARE PARTS LIST

MODEL NO. 9901

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
054	321979-5	TENSION ROLLER SHAFT	1	
055	912131-2	COUNTERSUNK HEAD SCREW M4X18	4	
056	343353-7	SAFETY PLATE	1	
057	231033-6	COMPRESSION SPRING 11	1	
058	168157-4	DRIVING ROLLER	1	
059	*****	*****	***	*****
060	157669-2	MOTOR HOUSING (R)	1	
061	321980-0	SUPPORT PIN	1	
062	411594-4	SHOE	1	
063	343355-3	STEEL PLATE	1	
064	423149-3	CORK RUBBER PLATE	1	
065	155873-7	EDGE SLIDER	1	
066	*****	*****	***	*****
067	*****	*****	***	*****
068	232092-3	LEAF SPRING	1	
400	794121-5	ABRASIVE BELT 76X533 WA80	1	